


FRONT PIVOTS AND HUBS-HUB BEARING



4131K01A 06/2007 AF 50B01A

01	3646 88 3647 88	01 01	FRONT SWIVEL PIN LEFT RIGHT
02	3520 Q2 3521 L3 16 073 046 80 16 073 047 80	01 01 01 01	WISHBONE FRONT LEFT ENS RIGHT ENS EM:SUSPENSION ARM PSA LEFT RIGHT
03	3307 82	02	WHEEL HUB
04	3623 21	02	BALL-JOINT PROTECTOR
70	6822 00	02	SCREW
71	6822 38	02	THREADED FLANGE BOLT
72	6822 A2	02	HEX HEAD SCREW+CAPTIVE WASHER
73	6822 A3	02	HEX HEAD SCREW+CAPTIVE WASHER
74	6822 SW	02	CASTLE NUT
75	6822 TT 3297 34 <i>RP 6822 TT</i>	02 02 01	NUT - UNTIL RPO 10993 WHEEL HUB FIXING NUT - SINCE RPO 10994
76	6822 SR	02	BASE NUT
77	6822 Q3	02	FIXING CLIP
78	6822 JL	02	WHEEL HUB BEARING
79	6822 JN	02	STOP-RING
80	6822 P4	02	FIXING CLIP