


24/09/11 335103

SPINDLES FORKS GEAR CHANGE CONTROL INT*BVM BE3 SINCE GEARBOX 8389938 UNTIL GEARBOX 8831000*

A)+2519 74 (01) + 2554 62 (01) + 2382 23 (01) + 2381 39 (01)



01	2553 52 LE-0002	01	MANUAL GEAR-BOX FORK 1+2
02	2554 60 NFP	01	MANUAL GEAR-BOX FORK 3+4
03	2546 38	01	FORK SHAFT 1-2-3-4
04	2549 14	01	MANUAL GR-BX FORK STOP PLATE
05	2538 07	03	LOCKING BALL DIAM 8
06	2539 52	03	FORK SPRING 5,3 X 7,7 - 35,55
07	2558 27 NFP	01	MANUAL GEAR-BOX FORK+PIN
08	2552 08 NFP 2552 19 LE-2008	01 MAR - UNTIL GEARBOX 8710288 01 MAR START B 8710289 (SEE A)	REVERSE ROCKING MEMBER
09	2552 06	01	REVERSE ROCKING MEMBER SHAFT MAR DIAM 12
10	2540 33	01	REVERSE LOCKING FINGER
11	2539 34	01	GEARSHIFT LOCKING SPRING
12	2519 68 NFP	01	MANUAL GRBX GRSHIFT SPNDL+FING
13	2525 40	01	MANUAL GEAR-BOX SELECTION LEVR
14	2541 20	01	O-RING DIAM 15X21-3
15	2527 34	01	GEAR-BOX CONTROL LEVER SPRING
16	2528 16	01	MANUAL GR-BX SEL SPRING BRACKT
17	2515 22	01	MANUAL GEARSHIFT SHAFT SEAL DIAM 16X30-7-11
70	6969 60	02	PIN 3,3X15
71	6921 09	01	HEX HEAD CAPSCREW DIAM 7X100-22
72	6934 28	01	NUT WITH BASE DIAM 12X150-12-26
73	6968 23	01	PIN DIAM 3 LON 15
74	6968 71	01	PIN DIAM 4,5 LON 22
75	6913 98	01	SCREW DIAM 7X100-22
76	6947 84	01	GEARSHIFT CONTROL SHAFT WASHER 16X28-1
77	6968 A7	01	PIN E7 L25 - DIA7,25
78	6968 C1	01	CENTRING PIN E7 L32
81	6979 86	01	STOP-RING S7,5X13,3-0,8